UltraStand

Notebook stand

BAKKER ELKHUIZEN

Work Smart - Feel Good

WARNING:

After removing the cover sheet from the UltraStand laptop holder, immediately attach it to your laptop!

First ensure that the back of the laptop is clean and grease-free (using, for example, a screen cloth).

1. Lay your laptop with the bottom facing up and the front facing you.
2. Carefully remove the cover sheet from the UltraStand.
3. Ensure that the UltraStand is facing you with the adjusting tongue pointing towards you.
4. Attach the UltraStand to the laptop using the reference points that correspond with the rear legs of your laptop.
5. Rub the sticky sheet on the sides with your fingertips (not your fingernails) and press the sticky pad down firmly in the middle. Ensure that the UltraStand lines up properly everywhere.
6. After 24 hours, the bond is at full strength and the UltraStand is ready for use.



Keep the cover sheet. You can stick the UltraStand to this, when you temporarily remove it to service your laptop. Exposing the UltraStand to the air must be kept to a minimum to prevent drying out.

Go to **www.bakkerelkhuizen.com/ultrastand** for a video instruction for attaching and detaching the UltraStand.